


JONES™ Rebar Clamps – Direct Burial

CAT. NO.	REBAR SIZE	WIRE RANGE - CU ONLY
J29-DB	3/8" (#3)	#8SOL- 6SOL
J30-DB	1/2" (#4)	#8SOL- 4STR
J31-DB	5/8" (#5)	#6SOL- 2/0STR*
J32-DB**	1/2", 5/8", 3/4" (#4, #5, #6)	#6SOL - 4/0STR



INSTALLATION INSTRUCTION

- 1- Assure that the rebar and wire are clean.
- 2- Position clamp on rebar and insert wire. Snug the screw.
- 3- With a slight motion, seat the internal gripping teeth on the smooth rebar surfaces, not the lands (projections).
- 4- Torque the screw to 150 in-lbs.

NOTE: J-series clamps are designed for bare rebar only.

Do not use on ground rod, pipe, or epoxy-coated rebar.



GREAVES

*UL listed for #4STR-#2STR

**UL pending

6/2005 rev 8/2008

GREAVES CORP. CLINTON, CT 860-664-4505 www.greaves-usa.com